



**GUARDTEC**

# Update Firmware



1-800-4-PULSAR

## 1 Access the firmware update webpage:



- A. Navigate to [pulsarpools.com/firmware](https://pulsarpools.com/firmware)
- B. Enter the password **guardtec2023** (case sensitive) to login for access to the firmware update file

## 2 Download the update .zip folder

## 3 Create a new folder for the update files




## 4 Extract the downloaded .zip folder into the folder you created




**More >>**

## 5 Run the .exe file (Application file) by double clicking on it



## 6 Follow the application instructions:


A. Connect the Full Chemistry Controller (FCC) to the PC USB Port via USB cable.




B. On the GuardTec screen, navigate to “Setup” > “Factory” > “Firmware Update”.

C. Press the “Firmware Update” button.

D. The update process will start automatically.



*Update process has started*



*Update process is complete*

## 7 Once the update process is complete, disconnect the USB cable from the FCC

## 8 Power cycle the GuardTec by unplugging it from power for 5 seconds

## 9 Configure the GuardTec (enter setpoints, add facility information, etc...)

GuardTec settings re-configuration will be required after any firmware update.